

# Bars Professional



**INFINITI / NISSAN 1990 - 2011**

VERSION: 2V09 DATE: NOV, 2012

## MODELS EQUIPPED WITH 14-PIN CONNECTOR AND OBD-II CONNECTOR (**NON-CAN VEHICLES**) (NOTE 1)

SYSTEM	YEAR	DATA STREAM	CAN COMMUNICATION CHECK	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
<b>ENGINE</b> Petrol Engine	- 2011	+		+	+	+(Note 13)
<b>ENGINE</b> Diesel Engine	- 2011	+	+	+	+	+(Note 9)
<b>ENGINE</b> TSURU in Mexico	- 2011	+		+	+	+(Note 13)
<b>A/T</b> Automatic Transmission	- 2011	+		+	+	
<b>NCVT</b> Nissan Continuous Variable Transmission	- 2011	+		+	+	
<b>ABS</b> Anti-Brake System	- 2011	+	+	+	+	+(Note 2)
<b>SRS</b> Air Bag	- 2011			+	+	
<b>TCS</b> Traction Control System	- 2011			+	+	
<b>4WD</b> 4-Wheel Drive	- 2011	+		+	+	
<b>D/SUS</b> Dumping Suspension	- 2011			+	+	
<b>NATS</b> Nissan Anti-Theft System	- 2011			+	+	+ Initialization Coding
<b>IVMS</b> In Vehicle Multiple System	- 2011			+	+	
<b>BCM</b> Body Control Module	- 2011			+	+	
<b>SMART ENTRANCE</b>	- 2011			+	+	+
<b>HEAD LAMP LEVELIZER</b>	- 2011			+	+	

SYSTEM	YEAR	DATA STREAM	CAN COMMUNICTION CHECK	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
<b>ADP</b> Automatic Drive Positioner	– 2011			+	+	
<b>EPS</b> Electronic Power Steering	– 2011	+		+	+	
<b>ASCD</b> Automatic Speed Control Device	– 2011			+	+	
<b>TPMS</b> Tire Pressure Monitoring System	– 2011			+	+	
<b>ICC</b> Intelligent Cruise Control	– 2011			+	+	
<b>e-4WD</b> Electric 4-Wheel Drive	– 2011			+	+	
<b>VDC</b> Vehicle Dynamic Control	– 2011			+	+	
<b>ACTIVE SUSPENSION</b>	– 2011			+	+	
<b>HICAS</b> High Capacity Actively Controlled Suspension	– 2011			+	+	
<b>AIR LEVELIZER</b>	– 2011			+	+	
<b>DIFFERENTIAL LOCK</b>	– 2011			+	+	
<b>REAR VIEW CAMERA</b>	– 2011			+	+	
<b>DISTANCE CONTROL</b>	– 2011			+	+	
<b>BATTERY CONTROLLER</b>	– 2011			+	+	
<b>ACTIVE ENGINE MOUNT</b>	– 2011			+	+	
<b>CHANGER COMMUNICATION</b>	– 2011			+	+	
<b>TORQUE CONTROL</b>	– 2011			+	+	
<b>TK ECU TYPE LKA</b> Lane Keeping Assist	– 2011			+	+	
<b>TK ECU TYPE</b> Lane Keeping Assist	– 2011			+	+	
<b>MOTOR ASSIST</b>	– 2011			+	+	
<b>MTR CONTROL</b>	– 2011			+	+	

SYSTEM	YEAR	DATA STREAM	CAN COMMUNICTION CHECK	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
<b>MTR Control (B)</b>	– 2011			+	+	
<b>MTR Control (B)-SUB</b>	– 2011			+	+	
<b>MTR Control (C)</b>	– 2011			+	+	
<b>MTR SUB</b>	– 2011			+	+	

**MODELS EQUIPPED WITH OBD-II CONNECTOR (ONLY CAN SYSTEMS) (NOTE 3)**

SYSTEM	YEAR	DATA STREAM	CAN COMMUNICTION CHECK	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
<b>ENGINE</b> Petrol Engine	– 2011	+		+	+	+(Note 6,7)
<b>ENGINE</b> Diesel Engine	– 2011	+		+	+	
<b>AT / CVT</b> Automatic Transmission	– 2011	+		+	+	+(Note 10)
<b>AWD / 4WD</b> All Wheel Drive / 4-Wheel Drive	– 2011			+	+	
<b>e-4WD</b> Electric 4-Wheel Drive	– 2011			+	+	
<b>ABS</b> Anti-Brake System	– 2011			+	+	+(Note 11)
<b>SRS</b> Airbag	– 2011			+	+	
<b>ICC</b> Intelligent Cruise Control	– 2011			+	+	
<b>IKEY</b> Intelligent Key	– 2011	+	+	+	+	+(Note 8)
<b>EPS</b> Electronic Power Steering	– 2011	+	+	+	+	
<b>ADP</b> Auto Drive Positioner	– 2011			+	+	
<b>IPDM E/R</b> Intelligent Power Distribution Module in the Engine Room	– 2011	+		+	+	
<b>TPMS</b> Tire Pressure Monitor	– 2011			+	+	+(Note 5)
<b>Meter</b> Instrument Cluster	– 2011			+	+	
<b>Meter &amp; A/C Amplifier</b> Instrument Cluster & A/C Amplifier	– 2011			+	+	
<b>BCM</b> Body Control Module	– 2011	+	+	+	+	+(Note 4)
<b>EHS</b> Easy Hill Start	– 2011			+	+	

<b>4WAS FRONT</b> 4-Wheel Active Steering	– 2011			+	+	
<b>4WAS MAIN</b> Four Wheel Active Steering	– 2011			+	+	
<b>RAS / HICAS</b> High Capacity Controlled Suspension	– 2011					
<b>ASD</b> Auto Slide Door	– 2011			+	+	
<b>AUTO SLIDE DOOR RIGHT</b>	– 2011			+	+	
<b>PRECRASH SEATBELT</b>	– 2011			+	+	
<b>ADAPTIVE LIGHT</b>	– 2011			+	+	
<b>MULTIMEDIA A/V</b>	– 2011			+	+	
<b>DIU</b> Data Interface Unit	– 2011			+	+	
<b>LDW</b> Land Departure Warning	– 2011			+	+	
<b>HVAC</b> Heating, Ventilation, Air Conditioning	– 2011			+	+	
<b>NATS5</b> Nissan Anti-Theft System	– 2011			+	+	NATS C/U Initialization
<b>POWER BACK DOOR</b>	– 2011			+	+	
<b>E-SUS</b> Electronic Suspension	– 2011			+	+	
<b>POPUP ENGINE HOOD / BORNET</b>	– 2011			+	+	
<b>ABS / ECB HYBRID</b>	– 2011			+	+	+

**MODEL GT-R R35**

SYSTEM	YEAR	DATA STREAM	CAN COMMUNICTION CHECK	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
<b>ENGINE</b> Petrol Engine	– 2011	+		+	+	
<b>A/T</b> Automatic Transmission	– 2011	+		+	+	+(note 12)
<b>AWD / 4WD</b> A-Wheel Drive / 4-Wheel Drive	– 2011			+	+	
<b>e-4WD</b> Electric 4-Wheel Drive	– 2011			+	+	
<b>ABS</b> Anti-Brake System	– 2011			– 2011	– 2011	+(note 11)
<b>SRS</b> Airbag	– 2011			– 2011		
<b>ICC</b> Intelligent Cruise Control	– 2011			+	+	
<b>IKEY</b> Intelligent Key	– 2011			+	+	
<b>EPS</b> Electronic Power Steering	– 2011			+	+	
<b>IPDM E/R</b> Intelligent Power Distribution Module in the Engine Room	– 2011			+	+	
<b>TPMS</b> Tire Pressure Monitor	– 2011			+	+	+(note 5)
<b>Meter &amp; A/C Amplifier</b> Instrument Cluster & A/C Amplifier	– 2011			+	+	
<b>BCM</b> Body Control Module	– 2011			+	+	
<b>EHS</b> Easy Hill Start	– 2011			+	+	
<b>PRECRASH SEATBELT</b>	– 2011			+	+	
<b>ADAPTIVE LIGHT</b>	– 2011			+	+	
<b>MULTIMEDIA A/V</b>	– 2011			+	+	
<b>DIU</b> Data Interface Unit	– 2011			+	+	
<b>HVAC</b>	– 2011			+	+	

Heating, Ventilation, Air Conditioning						
<b>NATS5</b> Nissan Anti-Theft System	– 2011			+	+	
<b>E-SUS</b> Electronic Suspension	– 2011			+	+	
<b>HEAD LAMP LEVELIZER</b>	– 2011			+	+	
<b>POPUP ENGINE HOOD / BONNET</b>	– 2011			+	+	

## BCM ITEMS

	SYSTEM	DATA STREAM	READ CODE	CLEAR CODE	ACTIVATION AND WORK SUPPORT
BCM	IMMU	+			+
	INTELLIGENT KEY	+			+
	MULTI REMOTE ENT	+			+
	THEFT ALM	+			+
	AIR CONDITIONER	+			+
	DOOR LOCK	+			+
	TRUNK	+			+
	INT LAMP	+			+
	HEAD LAMP	+			+
	AIR PRESSURE MONITOR	+			+ (Note 5)
	BATTERY SAVER	+			+
	BUZZER	+			+
	COMB SW	+			+
	FLASHER	+			+
	FUEL LID	+			+
	PANIC ALARM	+			+
	REAR DEFOGGER	+			+
	RETAINED PWR	+			+
	SIGNAL BUFFER	+			+
	WIPER	+			+
	SEC-E C/U OR BCM C/U	CAN communication check	+	+	
	KEYLESS ENTRY	+			+
	KEY REMINDER	+			+
	CHILD LOCK	+			+
	H/L EASH	+			+
	DIRECTION INDICATORS	+			+

Note:

1. Some of early models, Automatic Transmission, ABS and Air bag systems have no digital protocol communication capability. It might be used jumping wire to energize the impulse codes or flash codes on Instrument cluster.
2. ABS WORK SUPPORT, include:
  - (1) Steering angle adjust.
  - (2) Deceleration G sensor calibration.
  - (3) Side G sensor calibration.
  - (4) Pressure sensor calibration.
- ABS Activation: (The software will detect the functions are supported by the ECU or not)
  - (1) Fr Rh Solenoid
  - (2) Fr Lh Solenoid
  - (3) Rr Rh Solenoid
  - (4) Rr Lh Solenoid
  - (5) Rear Solenoid
  - (6) Abs Motor
  - (7) Front Solenoid
  - (8) Rear Solenoid
  - (9) Fr Rh Abs Solenoid(Act)
  - (10) Fr Lh Abs Solenoid(Act)
  - (11) Rr Rh Abs Solenoid(Act)
  - (12) Rr Lh Abs Solenoid(Act)
  - (13) Front Abs Solenoid(Act)
  - (14) Rear Abs Solenoid(Act)
  - (15) Slip Lamp
  - (16) Abs Warning Lamp
  - (17) Vdc Warning Lamp
  - (18) Tcs Fail Signal
  - (19) Ascd Signal
  - (20) Booster Drive
  - (21) Stop Lamp On Relay
3. A car may equip with CAN system and non-CAN system together.
4. **BCM** Functions supported : BCM NUMBER READER, STEERING LOCK RELEASE.
5. **TPMS**, Tire Pressure Sensor: Read ID, Register ID
6. **PETROL ENGINE** system, Work Support:
  - (1) Idle Air Flow Learning
  - (2) Ignition Timming Adjustment
  - (3) Idle Speed Adjustment
  - (4) Self-Learning Control

- (5) TPS learned value reset
  - (6) TPS close position learning
  - (7) (TBD) MT Learning
  - (8) VVEL position sensor adjustment
  - (9) **VIN REGISTRATION**
7. **PETROL ENGINE** system, Activation: (The software will detect the functions are supported by the ECU or not)
- (1) Alternator Duty
  - (2) Cooling Fan
  - (3) Engine Coolant Temperature
  - (4) Engine Mounting
  - (5) Fan Duty Control
  - (6) Fuel Injecting
  - (7) Fuel Pump Relay
  - (8) Fuel Tank Temperature sensor
  - (9) Ignition Timming
  - (10) Power Balance
  - (11) Purge Volume Control Valve
  - (12) Tumble Control Valve
  - (13) Vent Control Valve
  - (14) VIAS solenoid Valve
  - (15) VIAS solenoid Valve B2.
8. **I-KEY** functions:
- (1) Register I-KEY number
  - (2) Check I-KEY remote position.
9. **DIESEL ENGINE**, Work Support:
- (1) Injector Adjustment Value Registration
  - (2) DPF Service Regeneration
  - (3) DPF Data Clear
  - (4) Configuration Clear
  - (4) Injector Adjustment Value Clear
  - (5) A/F Sensor Learn Clear
  - (6) EGR Valve Learn Clear
  - (7) (TBD)ETC Positioner Clear
  - (8) Pump Learnt Clear
10. **AT / CVT**, Work Support: Confirm CFTF Deteriora
11. **ABS**, Work Support:
- (1) Deceleration G Sensor Calibration
  - (2) Valve Calibration
  - (3) Steering Angle Sensor Adjustment
  - (4) Side G sensor calibration
  - (5) Pressure sensor calibration
  - (6) Yaw rate/Side/Deceleration G sensor calibration

12. **A/T** for GT-R R35, Work Support: Clutch Gear Learning

13. **ENGINE SYSTEM, WORK SUPPORT:**

- (1) Check Fuel Lines
- (2) Closed TH/SW Adjust (IACV-AAC/V, 0 Step)
- (3) Closed TH/SW Adjust (IACV-AAC/V, 0%)
- (4) Closed TH/SW Adjust (IACV-IDLE/UP, Off)
- (5) Closed TH/SW Adjust
- (6) CO Adjustment
- (7) Ethanol M/R Adjust
- (8) EVAP System Close
- (9) Exhaust V/T Control Learn
- (10) Fuel Pressure Release
- (11) IACV-AAC/V Adjust
- (12) Idle Air Volume Learn
- (13) Idle Air Volume Learn Adjust
- (14) Idle RPM Adj
- (15) Idle RPM Adjust
- (16) Ignition Timing Adjust
- (17) Self-Learning Control
- (18) Self-Learning Control
- (19) Set Idle Speed
- (20) Target Idle RPM Adjust
- (21) Target Ign Timing Adjust
- (22) TP Sw/TP Sensor Idle Position Adjust
- (23) TPS Idle Position
- (24) V/T Control Learn
- (25) VIN Registration

**ENGINE SYSTEM, ACTIVATION:**

- (1) Air Conditioner Relay
- (2) Clear Self-Learning Control Value
- (3) Coolant temperature
- (4) Cooling Fan
- (5) EGR Volume Control
- (6) EGRC Solenoid Valve
- (7) Engine Coolant Temperature
- (8) Engine Mounting
- (9) FPCM
- (10) Fuel Injection
- (11) Fuel Pump Relay
- (12) Fuel Temperature Sensor
- (13) IAC/AAC valve
- (14) IACV-AAC Opening

- (15) Ignition Timing
- (16) Power Balance
- (17) Pressure Regulator
- (18) Purge Vol Control Valve/EAVP valve
- (19) Swirl Control Solenoid Valve
- (20) Target Fan RPM
- (21) Valve Timing Solenoid
- (22) Valve Timing Solenoid
- (23) Vent Control Valve
- (24) VIAS Solenoid Valve.