

BarsIII Professional



Mercedes-Benz

Mercedes-Benz 1987–2012

May 2014

A-class (168)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ECM/MSM (Engine Control Monolith)	+	+	+	+	
	CDI 1 (Common Rail Diesel Injection)	+	+			
	ACS (Automatic Clutch System)	+	+		+	
	FTC (Front Transmission Control)	+	+			
	GRM (Gear Recognition Module)	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	ATA (Anti-Thief Alarm)	+	+			
	LCP (Lower Control)	+	+	+		
	RFL (Radio Frequency Locking)		+			

INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	APS (Auto Pilot)		+			
SEATS AND DOORS	DCM 1	+	+	+		
	DCM 2	+	+	+		
	DCM 3	+	+	+		
	DCM 4	+	+	+		
AIR CONDITION	TAC / TAU (Tempmatic Air conditioning)	+	+			
	STH (Stationary Heater)		+			

A-class (169)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ESM (Electronic Selector Module)	+	+		+	
	FCVT (Continuously variable automatic transmission)	+	+			
	SIM266 (Engine System)	+	+			
	CDI A (Common Rail Diesel Injection)		+			
	CDI 4 (Common Rail Diesel Injection)	+	+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ES (Electrical Power Steering)	+	+			

BODY	AB (SRS / Airbag)	+	+			
	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch, without Keyless Go)	+	+			
	HRA-FL		+			
	HRA-FR		+			
	OCP (Overhead Control Panel)	+	+			
	SAM (Signal Acquisition and Actuation Module)	+	+			
INFO. And COMMUNICATION	IC (Instrument Cluster)	+	+		Service Reset	
	PTS (Parktronic System)	+	+			
	SCM (Steering Column Module)	+	+			
	ASSYST-PLUS	+	+		Service Reset	
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL		+			
	DCM RR		+			
AIR CONDITION	C-AAC (Convenience Automatic Air conditioning)	+	+	+	+	

B-class (245)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	FCVT (Continuously variable automatic transmission)	+	+			
	SIM266 (Engine System)	+	+			
	ESM (Electronic Selector Module)	+	+		+	

	CDI A (Common Rail Diesel Injection)		+			
	CDI 4 (Common Rail Diesel Injection)	+	+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ES (Electrical Power Steering)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	CGW (Central Getaway)	+	+			
	EIS (Electronic Ignition Switch, without keyless Go)	+	+			
	OCP (Overhead Control Panel)	+	+			
	SAM (Signal Acquisition and Actuation Module)	+	+			
	XALWA-L (Xenon headlamp, left)	+	+			
	XALWA-R (Xenon headlamp, right)	+	+			
	AHE (Trailer recognition)	+	+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		Service Reset	
	PTS (Parktronic System)	+	+			
	SCM (Steering Column Module)	+	+			
	ASSYST-PLUS	+	+		Service Reset	
SEATS AND DOORS	DCM 1	+	+	+		
	DCM 2	+	+	+		
	DCM 3	+	+	+		
	DCM 4	+	+	+		
AIR CONDITION	C-AAC (Convenience Automatic Air Conditioning)	+	+	+	+	

C-class (201)

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
CIS-E		+			
ELR (Diesel Injection Electronic ISC)		+			
ESCM		+			
ASD (Automatic Locking Differential)		+			
AB (SRS / Airbag)		+			
Climate Control		+			

C-class (202)

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	LH-SFI	+	+	+	
	HFM-SFI	+	+	+	+
	PMS/PEC	+	+		
	ME 2.0 / 2.1	+	+	+	+
	SIM4LE	+	+		+
	EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+		
	DM	+	+		+
	EAG 722.5 (5-speed automatic ETC)	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+
	IFI / ERE (Electronic Inline injection)	+	+		
CHASSIS	ABS	+	+		
	ASR	+	+		
	ETS	+	+		

	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	ADS (Adaptive Damping System)		+			
BODY	AB (SRS / Airbag)	+	+			
	EIS (Electronic Ignition Switch)	+	+		+	
	ATA (Anti-Thief Alarm)	+	+			
	PSE	(before 97) +	+			
	SAM	+	+	+	+	
	OCP	+	+	+		
	LCP (Lower Control)	+	+	+		
	HRA		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TELE AID (K-wire)		+			
	DN (K-wire)		+			
	APS (Auto Pilot)		+			
SEATS AND DOORS	DCM 1	+	+	+		
	DCM 2	+	+	+		
	DCM 3	+	+	+		
	DCM 4	+	+	+		
	ESA-FL	+	+			

	ESA-FR	+	+			
AIR CONDITION	TAC / TAU (Tempmatic Air conditioning)	+	+		+	
	STH (Stationary Heater)	+	+			

C-class (203-CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	SIM4LE	+	+		+	
	SIM271	+	+			
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)			+		
	CDI 3			+		
	CDI 4			+		
CHASSIS	ESP (Electronic Stability Program)	+	+	+	+	
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch) / KG (keyless)	+	+		+	
	AB (SRS / Airbag)	+	+			
	SAM-FRONT	+	+	+		
	SAM-REAR	+	+			

	OCP	+	+		+	
	LCP (Lower Control)	+	+			
	UCP (Upper Control)	+	+			
	HRA-FL	+	+			
	HRA-FR		+			
	WSS (Weight Sensing System)	+	+		+	
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		+(more workshop functions)	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	SEATS AND DOORS	DCM FL	+	+	+	
DCM FR		+	+	+		
DCM RL		+	+	+		
DCM RR		+	+	+		
ESA – Driver		+	+			

	ESA – Passenger	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			

C-class (203 non-CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	SIM4LE	+	+		+	
	SIM4LSE	+	+		+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)		+			
	CDI 2 (Common Rail Diesel Injection)	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+		+	
	BAS (Brake Assist System)	+	+			
	VP (Vacuum Pump Brake Booster)	+	+			
BODY	EIS (Electronic Ignition Switch)	+	+		+	
	AB (SRS / Airbag)	+	+			
	KG (keyless Go)	+	+			
	PSE	+(before 1997)	+			

	SAM-FRONT	+	+	+	+	
	SAM-REAR	+	+		+	
	OCP	+	+		+	
	LCP	+	+			
	UCP	+	+			
	HRA-FL	+	+			
	HRA-FR		+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+	+	+(more workshop functions)	+
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+(include TV on Drive)	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TELE AID / E-Call		+			
	TV		+			
	SOUND		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	REAR AC		+			
	STH (Stationary Heater)	+	+			

C-class (204)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.7.2	+	+			
	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	ME 9.7 AMG	+	+			
	MED 9.7		+			
	MED 40	+	+			
	SIM4LE	+	+			
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
	FSCU (Fuel pump)	+	+			
	DTR (Distronic)		+			
	CDI 3		+			
	CDI 4		+			
	CDI 6		+			
CDID 2	+	+				
CDID 3		+				
CHASSIS	ABR (Adaptive Brake)	+	+			
	ADS (Adaptive Damping System)	+	+			
	ESP (Electric Stability Program)	+	+		+	
	TPC (Tire Pressure Control)	+	+			

BODY	CGW (Central Gateway)	+	+			
	EIS (Electronic Ignition Switch) / KG (keyless)	+	+			
	AB (SRS / Airbag)	+	+			
	SAM-FRONT	+	+	+		
	SAM-REAR	+	+			
	OCP	+	+	+	+	
	COU	+	+			
	KG	+	+			
	RevETR-LF	+	+			
	RevETR-RF	+	+			
	XALWA-L	+	+			
	XALWA-R	+	+			
	WSS (Weight Sensing System)	+	+		+	
	AHE (Trailer recognition)		+			
	SVMCM		+			
PSD (Control module Panoramic sliding roof)	+	+		+		
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+	+	+	(Service reset)
	SCM (Steering Column Module)	+	+	+		
	PTS (Parktronic System)	+	+	+		
	RFK	+	+			
	PSD (Panoramic Sliding Roof)	+	+		+	
SEATS AND DOORS	DCM FL	+	+	+	+	
	DCM FR	+	+	+	+	
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+	+		
	ESA – Passenger		+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	

E-class (124)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	LH-SFI	+	+	+	+	
	HFM-SFI	+	+	+	+	+
	PMS/PEC	+	+			
	EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
	DM	+ (digital mode only)	+		+	
	EAG 722.5 (5-speed automatic ETC)	+ (digital mode only)	+	+		
	BM	+ (digital mode only)	+		+	
	CFI/CIS		+			
	ESCM		+			
	DI		+			
	ELR (Diesel Injection)		+			
	IFI / ERE (Electronic Inline injection)	+	+			
	EDS (Electronic Diesel System)		+			
CHASSIS	ABS	+	+			
	ASR	+	+			
	ASD (Automatic Locking Differential)		+			
	4MATIC (4-Wheel Drive)		+			
BODY	AB (Airbag)	+ (digital mode only)	+		+ (digital mode only)	

	RCL (DAS2, Code 888)		+		
	CST		+		
	ATA	+	+		
CLIMATE	CLIMATE (Air conditioning)		+		

E-class (Coupe) (207 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	ME 9.7 AMG	+	+			
	MED 9.7		+			
	MED 17.7	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+			
	FSCU (Fuel pump)	+	+			
	DTR (Distronic)	+	+			
	SIM271 (Engine)	+	+			
	SGR (Radar Sensors Control unit)		+			
	CDID 2	+	+			
	CDID 3		+			
	CDI 6		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ADS (Adaptive Damping System)	+	+			
	TPC	+	+			
BODY	CGW (Central Gateway)	+	+			

	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	KG	+	+			
	SAM-Drive	+	+			
	SAM-Rear	+	+			
	OCP	+	+		+	
	RevETR-LF	+	+			
	RevETR-RF	+	+			
	XALWA-L	+	+			
	XALWA-R	+	+			
	WSS (Weight Sensing System)	+	+		+	
	AHE	+	+			
	SG-FOND (Rear Control Unit)		+			
	SVMCM	+	+			
INFO. and COMMUNICATION	IC (Instrument Cluster)	+	+		+	Oil reset
	SCM (Steering Column Module)	+	+			
	MFK (Multifunction Camera)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – UCI (Media Interface)	+	+			
	MOST – COMMAND	+	+			
	MOST – ZBE (Audio/COMMAND operating unit)	+	+			
	MOST – ZAN (Audio/COMMAND display)	+	+			
	MOST – DAB (Digital Audio Broadcasting)		+			
	MOST – DTA (Teleaid)		+			

	MOST – DTA (Teleaid) – Emergency call		+			
	MOST – DTA (Teleaid)-MB Info/Breakdown assistance		+			
	MOST – DTA (Teleaid)- Stolen Vehicle Tracking		+			
	MOST – DTA (Teleaid)- Vehicle Remote Unlocking/locking		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM L	+	+	+		
	DCM R	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+		+	

E-class (210)

	SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	LH-SFI	+	+	+	+	
	HFM-SFI	+	+	+	+	+
	PMS/PEC	+	+			
	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	SIM4LE	+	+			

	EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
	DM	+	+		+	
	EAG 722.5 (5-speed automatic ETC)	+	+	+		
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM	+	+		+	
	CDI 2	+	+	+		
	IFI / ERE (Electronic Inline injection)	+	+			
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	ADS (Adaptive Damping System)		+			
	VP (Vacuum Pump Brake Booster)	+	+			
	SPS (Speed Sensitive Power Steering)		+			
	TPC (Tire Pressure monitor)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	EIS (Electronic Ignition Switch)	+	+		+	
	ATA (Anti-Thief Alarm)	+	+	+		
	KFB	+	+			
	PSE	+	+			

	SAM	+	+	+	+	
	OCP	+	+	+		
	LCP (Lower Control)	+	+	+		
	HRA		+			
	SVMCM		+			
	RCL/RFL		+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TELE AID(K-wire)		+			
	DN(K-wire)		+			
	ICS		+			
	TV (TV tuner)		+			
	APS (Auto Pilot)		+			
SEATS AND DOORS	DCM 1	+	+		+	
	DCM 2	+	+		+	
	DCM 3	+	+		+	
	DCM 4	+	+		+	
	ESA-FL	+	+			
	ESA-FR	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

E-class (211 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	ME 9.7 AMG	+	+			
	MED 9.7		+			
	SIM4LE	+	+		+	
	SIM4LSE	+	+		+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)		+			
	DTR (Distronic) CAN version		+			
	CDI 2	+	+	+		
	CDI 3		+			
	CDI 4		+			
CDI 5		+				
CDI D		+				
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ENR (Electronic Level Control)	+	+		+	
	AIRmatic	+	+		+	
	TPC	+	+			
	SBC	+	+		+	

	ABR	+	+			
BODY	CGW (Central Gateway)		+		+	
	EIS (Electronic Ignition Switch) and KG	+	+		+	
	AB (SRS / Airbag)	+	+			
	SAM-Drive	+	+	+	+	
	SAM-Passenger	+	+	+	+	
	SAM-Rear	+	+	+	+	
	OCP	+	+		+	
	LCP (Lower Control)	+	+			
	UCP (Upper Control)	+	+			
	HRA	+	+			
	RevETR-LF		+			
	RevETR-RF		+			
	XALWA-L	+	+			
	XALWA-R	+	+			
	WSS (Weight Sensing System)	+	+		+	
	BCM (Battery control module)	+	+			
AHE	+	+				
System Diagnosis		+				
INFO. and COMMUNICATION	IC (Instrument Cluster)	+	+		+	
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)		+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			

	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	TLC (Trunk Lid Control)	+	+			
	HS (Seat Heater)	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+	+	+	
	HSW	+	+			
	STH (Stationary Heater)	+	+			

E-class (212 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	ME 9.7 AMG	+	+			
	MED 9.7		+			
	MED 17.7	+	+			
	MED 40	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+			
	FSCU (Fuel pump)	+	+			
	ISM (Intelligent Servo Module)	+	+		+	
	DTR (Distronic)	+	+			
	DSI (Direct Select interface)		+			
	SIM271 (Engine)	+	+			
	SGR (Radar Sensors Control unit)		+			
	CDID 2	+	+			
	CDID 3		+			
CDI 6		+				
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRmatic		+			
	TPM	+	+			
BODY	CGW (Central Gateway)	+	+			
	EIS (Electronic Ignition Switch) and KG	+	+			
	AB (SRS / Airbag)	+	+			
	KG	+	+			

	SAM-Drive	+	+			
	SAM-Rear	+	+			
	OCP	+	+		+	
	RevETR-LF	+	+			
	RevETR-RF	+	+			
	XALWA-L	+	+			
	XALWA-R	+	+			
	WSS (Weight Sensing System)	+	+		+	
	PSD (Panoramic Sliding Roof)	+	+		+	
	AHE		+			
	KDS (Trunk Lid Control)	+	+			
	SG-FOND (Rear Control Unit)	+	+			
	SVMCM		+			
INFO. and COMMUNICATION	IC(Instrument Cluster)	+	+		+	Oil reset
	SCM (Steering Column Module)	+	+			
	DSI (Direct Select Interface)		+			
	MFK (Multifunction Camera)	+	+			
	NSA (Night View Assist)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – UCI (Media Interface)	+	+			
	MOST – COMMAND	+	+			
	MOST – ZBE (Audio/COMMAND operating unit)	+	+			
	MOST – ZAN (Audio/COMMAND display)	+	+			
	MOST – DAB (Digital Audio Broadcasting)		+			
	MOST – DTA (Teleaid)		+			

	MOST – DTA (Teleaid) – Emergency call		+			
	MOST – DTA (Teleaid)-MB Info/Breakdown assistance		+			
	MOST – DTA (Teleaid)- Stolen Vehicle Tracking		+			
	MOST – DTA (Teleaid)- Vehicle Remote Unlocking/locking		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	AMKS-LF (Active Multicontour Seat (Driver))	+	+			
	AMKS-RF (Active Multicontour Seat (Passenger))	+	+			
	PPAMKS (Pneumatic pump for Active Multicontour Seat)	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+		+	
	LRH (Heated Steering Wheel)		+			

S-class (126)

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
Engine ESCM		+			
Engine CFI		+			
ELR (Diesel Injection Electronic ISC)		+			
EDS (Electronic Diesel System)		+			
ASD (Automatic Locking Differential)		+			
AB (SRS / Airbag)	+ (digital mode only)	+		+ (digital mode only)	
Climate Control		+			

S-class (140)

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING	
DRIVE	LH-SFI / LH-SFI LEFT	+	+	+	+	
	LH-SFI RIGHT	+	+	+	+	
	HFM-SFI	+	+	+	+	
	ME 1.0 LEFT BANK	+	+	+	+	
	ME 1.0 RIGHT BANK	+	+	+	+	
	ME 1.0 V8	+	+	+	+	
	ME 2.0 / 2.1	+	+	+	+	
	EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
	DM	+	+		+	
	BM	+	+			
EAG 722.5 (5-speed automatic ETC)	+	+	+			

	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	IFI / ERE (Electronic Inline injection)	+	+			
	DI		+			
	EDS		+			
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	SPS (Speed Sensitive Power-Steering)		+			
	ASD (Automatic Locking Differential)		+			
	ADS (Adaptive Damping System)		+			
BODY	AB (SRS / Airbag)	+	+			
	IC (Instrument Cluster)	+	+		+	
	ATA (Anti-Thief Alarm)	+	+			
	IRC (IR Controller)		+			
	RCL(DAS1/X)		+			
	RFL(DAS2/X)		+			
	CF/KFB		+			
	PSE	+	+			
	HRA	+	+			
PTS	+	+				
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

S-class (220 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 2.7	+	+			
	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)		+			
	CDI 2	+	+	+		
	CDI 3		+			
	CDI 4		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRmatic (Suspension)	+	+	+	+	
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	CGW (Central Gateway)		+		+	
	EIS (Electronic Ignition Switch)	+	+		+	
	AB (SRS / Airbag)	+	+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			

	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	HRA	+	+			
	HLCM-L (Left headlamp)	+	+			
	HLCM-R (Right headlamp)	+	+			
	KG (keyless Go)	+	+			
	SAM-FRONT LEFT	+	+		+	
	SAM-FRONT RIGHT	+	+			
	SAM-REAR	+	+		+	
	PSE (Pneumatic system)	+	+		+	
	OCP	+	+			
	UCP (Upper Control)	+	+			
	System Diagnosis		+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			

	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			
	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TV (TV Tuner)		+			
	D2B – DN		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	ESA – R	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	OSB-FL (Multicontour backrest front left)	+	+			
	OSB-FR (Multicontour backrest front Right)	+	+			
	OSB-R (Multicontour backrest rear)	+	+			

AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	KLA (Climate Control)	+	+	+		
	REAR AC	+	+			
	STH (Stationary Heater)	+	+			
	HSW (Heated Steering Wheel)	+	+			

S-class (220 non CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 1.0	+	+	+	+	+
	ME 2.0 / 2.0 V8	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 2.7	+	+			
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)			+		
	CDI 2	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRmatic (Suspension)	+	+	+	+	
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			

	HRA	+	+			
	KG (keyless Go)	+	+			
	SAM-FRONT LEFT	+	+		+	
	SAM-FRONT RIGHT	+	+			
	SAM-REAR	+	+		+	
	PSE (Pneumatic system)	+	+		+	
	OCP	+	+			
	UCP (Upper Control)	+	+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			
	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TV (TV Tuner)		+			
	D2B – DN		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	ESA – R	+	+			

	OSB-FL (Multicontour backrest front left)	+	+			
	OSB-FR (Multicontour backrest front Right)	+	+			
	OSB-R (Multicontour backrest rear)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	KLA (Climate Control)	+	+	+		
	REAR AC	+	+			
	STH (Stationary Heater)	+	+			
	HSW (Heated Steering Wheel)	+	+			
	TSTH (Radio Remote Control STH)			+		

S-class (221 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+			
	MED 9.7		+			
	MED 2.7.2 (V12)	+	+			
	ME 17.7	+	+			
	MED 17.7	+	+			
	ME 2.7.2 (V12)	+	+			
	EGS 722.9	+	+		+	
	ISM (Intelligent servo module)	+	+	+		
	DTR (Distronic)			+		
SGR (Radar sensors control unit)			+			

	CDI 4		+			
	CDI 5		+			
	CDI 6		+			
	CDID 3		+			
CHASSIS	ABR (Adaptive Brake)	+	+			
	AIRmatic (Suspension)	+	+	+		
	EPB (Electronic parking brake)	+	+			
	TPC (Tire Pressure)	+	+			
	RBS (Regenerative braking system)	+	+			
	EHPS (Electrohydraulic Power Steering)		+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	WSS (Weight sensing system)		+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	XALWA-L (Left headlamp)	+	+			
	XALWA-R (Right headlamp)	+	+			
	KG (keyless Go)	+	+			
	SAM-Driver	+	+		+	
	SAM-REAR	+	+		+	
	PSE (Pneumatic system)		+			
	OCP	+	+			
UCP (Upper Control)	+	+				

	COU – ZBE (Central operating unit)	+	+			
	HBF (Rear control field / panel)		+			
	System Diagnosis		+			
	BNS (Vehicle power supply control module)	+	+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
	PSD (Panoramic sliding roof)		+			
	SG-BMS (Battery management system)		+			
	SG-DDW (DC/DC converter control unit)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)		+		+	
	NSA (Night View Assist)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	RFK (Backup camera)		+			
	COMAND		+			
	ZAN		+			
	TELEAID		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver	+	+			

	ESA – Passenger	+	+			
	ESA – R	+	+			
	DS-FL (Front Left Dynamic Seat)		+			
	DS-FR (Front Right Dynamic Seat)		+			
	DSP (Pneumatic pump for Dynamic Seat)		+			
	MKL-HL (Rear left Multicontour backrest)		+			
	MKL-HR (Rear right Multicontour backrest)		+			
	TLC (Truck lid control)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	KBE-H (Rear A/C operating unit)	+	+			
	STH (Stationary Heater)		+			

SLK-class (170)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	HFM-SFI	+	+	+	+	+
	PMS/PEC	+	+			
	ME 2.0 / 2.1	+	+	+	+	+
	SIM4LE	+	+			
	EAG 722.5 (5-speed automatic ETC)	+	+	+		
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	

	EGS 722.6 (5-speed automatic SEQ)	+	+		+	
	ESM	+	+			
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	VP (Vacuum Pump Brake Booster)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	ATA (Anti-Thief Alarm)	+	+			
	RFL		+			
	RFL / DAS2		+			
	HRA		+			
	VR	+	+			
	PSE	+	+			
	CCM	+	+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TELE AID (K-wire)		+			
AIR CONDITION	AAC / TAC (Tempmatic Air conditioning)	+	+			

SLK-class (171 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	SIM4LE	+	+			
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
CHASSIS	ESP (Electronic Stability Program)	+	+		+	
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	VR	+	+			
	HRA		+			
	OCP	+	+			
	UCP (Upper Control)	+	+			
	SAM-FRONT	+	+			
	SAM-REAR	+	+			
	System Diagnosis		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)		+			
	ASSYST (Active Service System)	+	+		+	
	ASSYST PLUS (PLUS Active Service System)		+		+	

	SCM (Steering Column Module)		+			
	PTS (Parktronic System)			+		
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM LEFT	+	+	+		
	DCM RIGHT	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	HS (Seat heater)	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+	+	+	

SLK-class (172)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	SIM271 (Engine)	+	+			
	MED 17.7	+	+			
	MED 40	+	+			
	EGS 722.9	+	+		+	
	FSCU (Fuel Pump)		+			
	ESM (Electronic Selector Module)	+	+			
	DTR (Distronic)	+	+			
	SGR (Radar sensors control unit)		+			
	CDID 2	+	+			
CDID 3		+				
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ADS (Adaptive Damping System)	+	+			
	TPM	+	+			
	EPB (Electronic Parking Brake)		+			
BODY	CGW (Central Gateway)	+	+			
	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)		+			
	KG	+	+			
	RevETR-LF	+	+			
	RevETR-RF	+	+			
	AIRSCARF		+			
SAM-Driver	+	+				

	SAM-REAR	+	+			
	SG-SW (Headlamp)		+			
	VDS (Vario Roof)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		Oil reset	
	MFK (Multifunction Camera)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – UCI (Media Interface)	+	+			
	MOST – COMMAND	+	+			
	MOST – ZBE [COU] (Audio/Comand Operating Unit)	+	+			
	MOST – ZAN (Audio/Comand Display)	+	+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	MOST – DAB (Digital Audio Broadcasting)		+			
	MOST – DTA (TELEAID)		+			
	MOST – DTA (TELEAID) – Emergency call		+			
	MOST – DTA (TELEAID) – MB info / Breakdown Assistance		+			
	MOST – DTA (TELEAID) – Stolen Vehicle Tracking		+			

	MOST – DTA (TELEAID) – Vehicle Remote Unlocking/Locking		+			
SEATS AND DOORS	DCM LEFT	+	+	+		
	DCM RIGHT	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)		+			

SLK-class (208)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	SIM4LE	+	+			
	EAG 722.5 (5-speed automatic ETC)	+	+	+		
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM	+	+		+	
	DTR			+		
	CDI 2	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	EIS (Electronic Ignition Switch)	+	+		+	

	HRA-FL	+ (partial)	+			
	HRA-FR	+ (partial)	+			
	UCP	+	+			
	LCP (Lower Control)		+			
	SAM-FRONT	+	+		+	
	SAM-REAR	+	+		+	
	AHE (Trailer recognition)		+			
	RVC (Rollover bar soft top control module)	+	+	+		
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	SCM	+	+			
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TV (TV tuner)		+			
	SOUND		+			
SEATS AND DOORS	DCM LEFT	+	+			
	DCM RIGHT	+	+			
	DCM REAR		+			
	ESA LEFT	+	+			
	ESA RIGHT	+	+			
	TLC		+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

SLK-class (209)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	SIM4LE	+	+			
	EAG 722.5 (5-speed automatic ETC)	+	+	+		
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM	+	+		+	
	DTR		+			
	CDI 2	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+		+	
BODY	AB (SRS / Airbag)	+	+			
	EIS (Electronic Ignition Switch)	+	+		+	
	HRA-FL	+	+			
	HRA-FR	+	+			
	OCP	+	+			
	UCP	+	+			
	LCP (Lower Control)	+	+			
	SAM-FRONT	+	+		+	
	SAM-REAR	+	+		+	
	AHE (Trailer recognition)		+			
	RVC	+	+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	SCM	+	+			

	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL1 (Cellular Telephone 1)		+			
	CTEL2 (Cellular Telephone 2)		+			
	VCS		+			
	TV (TV tuner)		+			
	SOUND		+			
SEATS AND DOORS	DCM LEFT	+	+			
	DCM RIGHT	+	+			
	DCM REAR		+			
	ESA LEFT	+	+			
	ESA RIGHT	+	+			
	TLC		+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			

SL-class (107)

SYSTEM	DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
Engine CFI		+			
AB (SRS / Airbag)	+	+		+	
	(digital mode only)			(digital mode only)	

SL-class (129)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	LH-SFI	+	+	+	+	
	HFM-SFI	+	+	+	+	+
	PMS/PEC	+	+			
	ME 2.0 / 2.1	+	+	+	+	+
	BM	+	+			
	EA / CC / ISC (with LH-SFI / HFM-SFI)	+	+			
	DM	+	+		+	
	EAG 722.5 (5-speed automatic ETC)	+	+	+		
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	CFI		+			
	DI					
	CDI 2	+	+			
IFI / ERE (Electronic Inline injection)	+	+				
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	ADS (Adaptive Damping System)		+			

	ASD (Automatic Locking Differential)		+			
BODY	AB (SRS / Airbag)	+	+			
	IR (IR controller)		+			
	ATA (Anti-Thief Alarm)	+	+			
	RFL	(before 1997)	+			
	RCL (DAS2/X)		+			
	APS		+			
	RB		+			
	RST		+			
	HRA		+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	PTS (Parktronic System)	+	+			
	D2B (AUDIO System)	+	+		+	
	CTEL1 (Cellular Telephone 1)		+			
	VCS		+			
	TELE AID(K-wire)		+			
	DN(K—wire)		+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

SL-class (230)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 1.0	+	+	+	+	+
	ME 2.0 / 2.0 V8	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	SBC	+	+		+	
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	HRA-Front Right		+			
	HRA-Front Left		+			
	KG (keyless Go)	+	+			
	SAM-Driver Side	+	+		+	
	SAM-Passenger Side	+	+			
	SAM-Rear	+	+		+	
	PSE	+	+			
	OCP	+	+			
	LCP (Lower Control)	+	+	+		
BNS (Vehicle power supply module)		+				

	RVC (Rollover bar / Vario Roof)	+	+	+		
	System Diagnosis		+			
SEATS AND DOORS	DCM LEFT	+	+	+		
	DCM RIGHT	+	+	+		
	ESA – LEFT	+	+			
	ESA – RIGHT	+	+			
	OSB-FL (Multicontour backrest Left)	+	+			
	OSB-FR (Multicontour backrest Right)	+	+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			
	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TELE AID		+			
	D2B – TV (TV Tuner)		+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

SL-class (230 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)		+			
CHASSIS	ESP (Electronic Stability Program)		+			
	SBC	+	+	+		
	ABC (Active Body Control)		+			
	TPC (Tire Pressure)		+			
BODY	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)		+			
	HRA-Front Right		+			
	HRA-Front Left		+			
	KG (keyless Go)		+			
	SAM-Driver Side	+	+		+	
	SAM-Passenger Side	+	+			
	SAM-Rear	+	+		+	
	PSE	+	+			
	OCP	+	+			
	LCP (Lower Control)	+	+	+		
	BNS (Vehicle power supply module)		+			
	RVC (Rollover bar / Vario Roof)	+	+	+		

	CGW		+			
	WSS	+	+		+	
	System Diagnosis		+			
SEATS AND DOORS	DCM LEFT	+	+	+		
	DCM RIGHT	+	+	+		
	ESA – LEFT	+	+			
	ESA – RIGHT	+	+			
	OSB-FL (Multicontour backrest Left)	+	+			
	OSB-FR (Multicontour backrest Right)	+	+			
	INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		+
SCM (Steering Column Module)		+	+			
PTS (Parktronic System)		+	+			
D2B		+	+		+	
D2B – CDC (CD Changer)			+			
D2B – CTEL1 (Cellular Telephone)			+			
D2B – CTEL2 (Cellular Telephone)			+			
D2B – VCS (Voice Control)			+			
D2B – SOUND (Bose SOUND System)			+			
D2B – TELE AID			+			
D2B – TV (TV Tuner)			+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

SLR-class (199)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 1.0	+	+	+	+	+
	ME 2.0/2.0 V8	+	+	+	+	+
	ME 2.8/2.8 AMG	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)			+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
	SBC	+	+		+	
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	HRA-Front Right		+			
	HRA-Front Left		+			
	KG (keyless Go)	+	+			
	SAM-Driver Side	+	+		+	
	SAM-Passenger Side	+	+			
	SAM-Rear	+	+		+	
	PSE	+	+			
	OCP	+	+			
	LCP (Lower Control)	+	+	+		
BNS (Vehicle power supply module)			+			

	RVC (Rollover bar / Vario Roof)	+	+	+		
	System Diagnosis		+			
SEATS AND DOORS	DCM LEFT	+	+	+		
	DCM RIGHT	+	+	+		
	ESA – LEFT	+	+			
	ESA – RIGHT	+	+			
	OSB-FL (Multicontour backrest Left)	+	+			
	OSB-FR (Multicontour backrest Right)	+	+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			
	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TELE AID		+			
	D2B – TV (TV Tuner)		+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

CLS-class (197 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	EGS	+	+		+	
	FSCU (Fuel Pump)	+	+			
	DSI (Direct Select Interfase)		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	EPB (Electronic Parking Brake)	+	+			
	TPM	+	+			
	AIRMATIC		+			
BODY	CGW (Central Gateway)	+	+			
	EIS (Electronic Ignition Switch) / KG (keyless)	+	+			
	AB (SRS / Airbag)	+	+			
	SAM-Driver	+	+	+		
	SAM-Rear	+	+			
	RevETR-FL	+	+			
	RevETR-FR	+	+			
	WSS (Weight Sensing System)	+	+		+	
	AMG DRVU (AMG Drive Unit)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+	+	Oil reset	
	SCM (Steering Column Module)	+	+	+		
	PTS (Parktronic System)	+	+			
	DSI (Direct Select Interfase)		+			

	MOST – UCI (Media Interface)	+	+			
	MOST – COMMAND	+	+			
	MOST – ZBE [COU] (Audio/Comand Operating Unit)	+	+			
	MOST – ZAN (Audio/Comand Display)	+	+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	MOST – DAB (Digital Audio Broadcasting)		+			
	MOST – DTA (TELEAID)		+			
	MOST – DTA (TELEAID) – Emergency call		+			
	MOST – DTA (TELEAID) – MB info / Breakdown Assistance		+			
	MOST – DTA (TELEAID) – Stolen Vehicle Tracking		+			
	MOST – DTA (TELEAID) – Vehicle Remote Unlocking/Locking		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	ESA – Driver	+	+	+		
	ESA – Passenger		+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)		+			

CLS-class (219 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)			+		
	CDI 4			+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRMatic	+	+			
	SBC	+	+		+	
	TPC	+	+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch) / KG (keyless)	+	+			
	AB (SRS / Airbag)	+	+			
	SAM-Driver		+			
	SAM-Passenger		+			
	SAM-Rear		+			
	RevETR-FL	+	+			
	RevETR-FR	+	+			
	OCP		+		+	
	LCP (Lower Control)		+			
	UCP (Upper Control)		+			

	HRA		+			
	WSS (Weight Sensing System)	+	+		+	
	System Diagnosis		+			
	BCM	+	+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)		+		+	
	SCM (Steering Column Module)		+			
	PTS (Parktronic System)		+			
	SCM (Steering Column Module)		+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	DCM RL	+	+	+		

	DCM RR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	TLC (Trunk Lid Control)	+	+			
	HS (Seat Heater)	+	+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)	+	+			
	HSW (Heated Steering Wheel)	+	+			

CL-class (215 non CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 1.0	+	+	+	+	+
	ME 2.0 / 2.0 V8	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 2.7	+	+			
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM (Electronic Selector Module)	+	+		+	
	DTR (Distronic)			+		
	CDI 2	+	+	+		

CHASSIS	ESP (Electronic Stability Program)	+	+			
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	HRA	+	+			
	SAM-FRONT LEFT	+	+		+	
	SAM-FRONT RIGHT	+	+			
	SAM-REAR	+	+		+	
	PSE (Pneumatic system)		+			
	OCP	+	+			
	UCP (Upper Control)	+	+			
	KG	+	+			
	AHE (Trailer recognition)		+			
SVMCM		+				
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			
	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TV (TV Tuner)		+			

	D2B – TELE AID		+			
	D2B – DN		+			
SEATS AND DOORS	DCM FL	+	+			
	DCM FR	+	+			
	DCM RL	+	+			
	DCM RR	+	+			
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	ESA – R	+	+			
	OSB-FL (Multicontour backrest front left)	+	+			
	OSB-FR (Multicontour backrest front Right)	+	+			
	OSB-R (Multicontour backrest rear)	+	+			
	AIR CONDITION	AAC (Automatic Air Conditioning)	+	+		
KLA (Climate Control)		+	+			
REAR AC		+	+			
STH (Stationary Heater)		+	+			
HSW (Heated Steering Wheel)		+	+			
TSTH (Radio Remote Control STH)			+			

CL-class (215 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 2.7	+	+			
	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ESM (Electronic Selector Module)	+	+			
	DTR (Distronic)		+			
	CDI 2	+	+	+		
CHASSIS	ESP (Electronic Stability Program)	+	+			
	ABC (Active Body Control)	+	+	+	+	
	TPC (Tire Pressure)	+	+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
	HRA	+	+			
	HLCM-L (Left headlamp)	+	+			

	HLCM-R (Right headlamp)	+	+			
	KG (keyless Go)	+	+			
	SAM-FRONT LEFT	+	+			
	SAM-FRONT RIGHT	+	+			
	SAM-REAR	+	+			
	PSE (Pneumatic system)		+			
	OCP	+	+			
	UCP (Upper Control)	+	+			
	System Diagnosis		+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	D2B	+	+		+	
	D2B – CDC (CD Changer)		+			

	D2B – CTEL1 (Cellular Telephone)		+			
	D2B – CTEL2 (Cellular Telephone)		+			
	D2B – VCS (Voice Control)		+			
	D2B – SOUND (Bose SOUND System)		+			
	D2B – TV (TV Tuner)		+			
	D2B – DN		+			
SEATS AND DOORS	DCM FL	+	+			
	DCM FR	+	+			
	DCM RL	+	+			
	DCM RR	+	+			
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	ESA – R	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	OSB-FL (Multicontour backrest front left)	+	+			
	OSB-FR (Multicontour backrest front Right)	+	+			
	OSB-R (Multicontour backrest rear)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	REAR AC	+	+			
	STH (Stationary Heater)	+	+			

	HSW (Heated Steering Wheel)	+	+			
	TSTH (Radio Remote Control STH)		+			

CL-class (216)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	EGS 722.9	+	+		+	
	ISM (Intelligent Servo Module)	+	+	+		
	DTR (Distronic)		+			
	SGR (Radar Sensors Control Unit)		+			
CHASSIS	ABR (Adaptive Brake)	+	+			
	EPB (Electronic Parking Brake)		+			
	ABC (Active Body Control)	+	+			
	TPC (Tire Pressure)	+	+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch)	+	+			
	AB (SRS / Airbag)	+	+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			

	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	WSS (Weight Sensing System)	+	+		+	
	XALWA-L (Left headlamp)	+	+			
	XALWA-R (Right headlamp)	+	+			
	KG (keyless Go)	+	+			
	SAM-Driver	+	+			
	SAM-REAR	+	+			
	OCP		+			
	UCP (Upper Control)	+	+			
	COU – ZBE (Central operating unit)	+	+			
	HBF (Rear control field / panel)		+			
	System Diagnosis		+			
	BNS (Vehicle power supply control module)	+	+			
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	IC (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)	+	+		+	
	NSA (Night View Assist)	+	+			
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)	+	+			
	RFK (Backup camera)	+	+			
	COMAND		+			
	ZAN		+			

	TELEAID		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)		+			
	DS-FR (Front Right Dynamic Seat)		+			
	DSP (Pneumatic pump for Dynamic Seat)		+			
	MKL-HL (Rear left Multicontour backrest)		+			
	MKL-HR (Rear right Multicontour backrest)		+			
	TLC (Truck lid control)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	KBE-H (Rear A/C operating unit)	+	+			
	STH (Stationary Heater)		+			

R-class (251)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	EGS 722.9	+	+		+	
	ISM (Intelligent servo module)	+	+	+		
	DTR (Distronic)		+			
	CDI 5		+			
CHASSIS	ENR (Electronic level control)	+	+			
	AIRmatic (Suspension)	+	+			
	ESP	+	+			
	TPC (Tire Pressure)		+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch) / KG (Keyless Go)	+	+			
	AB (SRS / Airbag)	+	+			
	WSS (Weight sensing system)		+		+	
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	HRA (Headlamp)		+			
	SAM-Front	+	+		+	
	SAM-REAR	+	+		+	
	OCP	+	+		+	
	UCP (Upper Control)	+	+			
	HBF (Rear control field / panel)	+	+			
	System Diagnosis		+			

INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)		+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)		+			
	CM (Compass Module)	+	+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	HS (Seat heater)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			
	HSW (Heated Steering Wheel)	+	+			

M-class (163)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8 AMG	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	EGS 722.6 (5-speed automatic SEQ)	+	+			
	ESM	+	+		+	
	TC / VG	+	+			
	CDI 2	+	+	+		
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			
	BAS (Brake Assist System)	+	+			
	VP (Vacuum Pump Brake Booster)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	AAM (All Activity Module)	+	+		+	
	EAM (Extended Activity Module)	+	+		+	
	DAS (Drive Auth. System)	+	+			
	LCP (Lower Control)	+	+			
	HRA	+	+			
	SEM (Security Module)		+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	PTS (Parktronic System)	+	+			

	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL (Cellular Telephone)		+			
	VCS		+			
	SOUND		+			
	TELE-AID		+			
SEATS AND DOORS	DCM FL	+	+			
	DCM FR	+	+			
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	HS (Seat heater)	+	+			
AIR CONDITION	TAC (Tempmatic Air conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			

M-class (164 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	EGS 722.9	+	+		+	
	CDI 3		+			
	CDI 4		+			
	TC / VG		+			
	ISM	+	+	+		
	HAQ		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRmatic (Suspension)	+	+		+	
	TPC (Tire Pressure)		+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch) / KG (Keyless Go)	+	+		+	
	AB (SRS / Airbag)	+	+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	HRA		+			
	SAM-FRONT	+	+			
	SAM-REAR	+	+			
	OCP	+	+		+	
	UCP (Upper Control)	+	+			
	HBF (Rear Control Field)	+	+			

	System Diagnosis		+			
	WSS (Weight Sensing System)	+	+		+	
	AHE (Trailer recognition)		+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			
	ASSYST PLUS (PLUS Active Service System)		+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)		+			
	CM (Compass Module)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+			
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			

	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	HS (Seat heater)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			
	HSW (Heated Steering Wheel)	+	+			

M-class (166)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	MED 17.7	+	+			
	EGS 722.9	+	+		+	
	ISM (Instrument Cluster)	+	+			
	SGR (Radar sensors control unit)		+			
	TC / VG		+			
	DTR (Distronic)	+	+			
	FSCU (Fuel Pump)	+	+			
	CDI 6		+			
	CDID 3		+			
CHASSIS	ESP (Electronic Stability Program)		+			
	AIRmatic (Suspension)		+		+	
	TPC (Tire Pressure)	+	+			

	EPB (Electronic Parking Brake)		+			
BODY	CGW (Central Gateway)	+	+			
	EIS (Electronic Ignition Switch) / KG (Keyless Go)		+			
	AB (SRS / Airbag)		+			
	RevETR-LF (Left front reversible emergency tensioning retractor)		+			
	RevETR-RF (Right front reversible emergency tensioning retractor)		+			
	KG		+			
	SAM-DRIVE	+	+			
	SAM-REAR	+	+			
	SVMCM		+			
	SD (Control module sliding roof)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)		+			
	MFK (Multifunction Camera)	+	+			
	RFK (Backup Camera)		+			
	SCM (Steering Column Module)		+			
	PTS (Parktronic System)		+			
	NSA (Night View Assist)	+	+			
	MOST – UCI (Media Interface)	+	+		+	
	MOST – COMMAND	+	+			
	MOST – ZBE [COU] (Audio/Comand Operating Unit)	+	+			
	MOST – ZAN (Audio/Comand Display)	+	+			

	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
	MOST – DAB (Digital Audio Broadcasting)		+			
	MOST – DTA (TELEAID)		+			
	MOST – DTA (TELEAID) – Emergency call		+			
	MOST – DTA (TELEAID) – MB info / Breakdown Assistance		+			
	MOST – DTA (TELEAID) – Stolen Vehicle Tracking		+			
	MOST – DTA (TELEAID) – Vehicle Remote Unlocking/Locking		+			
SEATS AND DOORS	DCM FL		+			
	DCM FR		+			
	ESA – Driver		+			
	ESA – Passenger		+			
	DCM RL		+			
	DCM RR		+			
	HKS (Tailgate Control)		+			
AIR CONDITION	C-AAC / AAC (Automatic Air Conditioning)		+		+	
	STH (Stationary Heater)		+			

G-class (463)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	ME 2.8 / 2.8AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM	+	+		+	
	VGS		+			
	HFM	+	+	+		
	CDI 2	+	+	+		
	CDI V	+	+			
	CDI 4 (Common Rail Diesel Injection)	+	+			
	CDI 6 (Common Rail Diesel Injection)			+		
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+				
	ESP (Electronic Stability Program)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	ATA	+	+			
	RFL		+			
	EIS	+	+		+	
	OCP		+		+	
	UCP		+			
	SAM-FRONT		+		+	
	SAM-REAR		+		+	
AHE		+				

	VR	+	+			
	SVMCM		+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	D2B (AUDIO System)	+	+		+	
	CDC (CD Changer)		+			
	CTEL (Cellular Telephone)		+			
	VCS		+			
	SCM		+			
	APS		+			
	TV		+			
	TELE-AID		+			
SEATS AND DOORS	DCM FL	+	+			
	DCM FR	+	+			
	DCM RL	+	+	+		
	DCM RR	+	+	+		
	ESA – Driver		+			
	ESA – Passenger		+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

GL-class (X164 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.8 / 2.8 AMG	+	+	+	+	
	ME 9.7	+	+	+	+	
	EGS 722.9	+	+	+	+	
	CDI 3		+			
	CDI 4		+			
	TC / VG		+			

	ISM	+	+	+		
	HAQ		+			
	DTR		+			
	FSCU (Fuel Pump)		+			
CHASSIS	ESP (Electronic Stability Program)	+	+			
	AIRmatic (Suspension)	+	+	+		
	TPC (Tire Pressure)		+			
BODY	CGW (Central Gateway)		+			
	EIS (Electronic Ignition Switch) / KG (Keyless Go)	+	+		+	
	AB (SRS / Airbag)	+	+			
	RevETR-LF (Left front reversible emergency tensioning retractor)	+	+			
	RevETR-RF (Right front reversible emergency tensioning retractor)	+	+			
	HRA		+			
	SAM-FRONT	+	+			
	SAM-REAR	+	+			
	OCP	+	+		+	
	UCP (Upper Control)	+	+			
	HBF (Rear Control Field)	+	+			
	System Diagnosis		+			
	WSS (Weight Sensing System)	+	+		+	
	AHE (Trailer recognition)		+			
	KG (Keyless Go)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+			
	ASSYST (Active Service System)	+	+			

	ASSYST PLUS (PLUS Active Service System)		+		+	
	SCM (Steering Column Module)	+	+			
	PTS (Parktronic System)		+			
	CM (Compass Module)	+	+			
	MOST – AGW	+	+		+	
	MOST – COMMAND / AUDIO		+			
	MOST – CDC (CD Changer)		+		+	
	MOST – HFS (Handsfree System and Microphone)		+			
	MOST – CTEL (Cellular Telephone)		+			
	MOST – VCS (Voice Control)		+			
	MOST – NAVI (Navigation)		+			
	MOST – SOUND (Bose SOUND System)		+			
	MOST – TV (TV Tuner)		+			
	MOST – SDAR (Satellite Radio)		+			
SEATS AND DOORS	DCM FL	+	+	+		
	DCM FR	+	+	+		
	ESA – Driver	+	+			
	ESA – Passenger	+	+			
	DS-FL (Front Left Dynamic Seat)	+	+			
	DS-FR (Front Right Dynamic Seat)	+	+			
	DSP (Pneumatic pump for Dynamic Seat)	+	+			
	HS (Seat heater)	+	+			

	ERA (Electric Fold-down Backrest System)	+	+			
	REDC (Rear-end door Closing Control Module)	+	+			
AIR CONDITION	AAC (Automatic Air Conditioning)	+	+	+	+	
	STH (Stationary Heater)	+	+			
	HSW (Heated Steering Wheel)	+	+			

SPRINTER (901,902,903,904,905)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM (Electronic Selector Module)	+	+		+	
	CDI 1	+	+		+	
	CDI 1.7	+	+			
	CDI 2	+		+		
	IFI	+	+			
CHASSIS	ABS	+	+			
	ASR	+	+			
	ETS	+	+			
	ESP (Electronic Stability Program)	+	+			

BODY	AB (SRS / Airbag)	+	+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	APS		+			
SEATS AND DOORS	DCM 1		+			
	DCM 2		+			
	ESA – Driver		+			
	ESA – Passenger		+			
AIR CONDITION	AAC /TAC (Automatic Air Conditioning)	+	+			
	STH (Stationary Heater)	+	+			

SPRINTER (906 CAN)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	VG	+	+			
	EGS 722.9	+	+	+	+	
	ESM (Electronic Selector Module)	+	+			
	CDI 4		+			
CHASSIS	TPC		+		+	
	ESP (Electronic Stability Program)	+	+			
BODY	AB (SRS / Airbag)	+	+			
	AAG (Trailer Connection Unit)		+			
	EIS (Electronic Ignition Switch)	+	+			
	HRA (Headlamp Range)	+	+			

	Adjustment)					
	KE (Keyless Entry)		+			
	OCP (Overhead Control Panel)		+			
	UCP (Upper Control Panel)		+			
	SCM (Steering Column Module)		+			
	SAM-F	+	+			
INFO. and COMMUNICATION	ICM / KI (Instrument Cluster)		+		Service Reset / Oil Quality	
	MTCO (Modular Tachograph)		+			
	PTS (Parktronic System)		+			
	AGW (Audio Gateway)		+			
SEATS AND DOORS	STL (Left Electric Sliding Door)		+			
	STR (Right Electric Sliding Door)		+			
	DCM (Door Control Module)	+	+			
AIR CONDITION	AAC /TAC (Automatic Air Conditioning)	+	+			
	PTC (Electric Heater Booster)	+	+			
	ZHZ (Heater Booster)	+	+			
	STH (Stationary Heater)	+	+			

VANEO

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ECM/MSM (Engine Control Monolith)	+	+			
	CDI 1 (Common Rail Diesel Injection)	+	+			

	ACS (Automatic Clutch System)		+			
	FTC (Front Transmission Control)			+		
	GRM (Gear Recognition Module)			+		
CHASSIS	ESP (Electronic Stability Program)	+		+		
	ESM	+		+		+
BODY	AB (SRS / Airbag)	+		+		
	ATA (Anti-Thief Alarm)	+		+		
	DAS (Drive Auth. System)	+		+		
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+		+		Service Reset / Oil Quality
	PTS (Parktronic System)	+		+		
	D2B (AUDIO System)	+		+		+
	CDC (CD Changer)			+		
	CTEL1 (Cellular Telephone 1)			+		
AIR CONDITION	TAC / TAU (Tempmatic Air conditioning)	+		+		
	STH (Stationary Heater)			+		

VITO/VIANO (636 CHINA)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 9.7	+	+	+	+	
	EGS 722.6 (5-speed automatic ETC)	+	+	+	+	
	ESM	+	+			
CHASSIS	ESP	+	+			
	ENR	+	+			

	TPC		+			
BODY	AB (SRS / Airbag)		+			
	OCP		+			
	UCP	+	+			
	SAM		+			
	EIS		+			
	AHE (Trailer recognition)		+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)		+			
	PTS	+	+			
SEATS AND DOORS	DCM FL		+			
	DCM FR		+			
	ESA – Driver		+			
	ESA – Passenger		+			
	ESD-L (Left Electric Sliding Door)		+			
	ESD-R (Right Electric Sliding Door)		+			
AIR CONDITION	AAC		+			
	STH (Stationary Heater)		+			

VITO(638)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	CDI 1 (Common Rail Diesel Injection)	+	+			
	CDI 2 (Common Rail Diesel Injection)	+	+	+		

	IFI	+	+			
CHASSIS	ABS	+	+			
BODY	AB (SRS / Airbag)	+	+			
INFO. and COMMUNICATION	ICM (Instrument Cluster)	+	+		Service Reset / Oil Quality	
	APS		+			
AIR CONDITION	TAC / TAU (Tempmatic Air conditioning)	+	+			
	STH (Stationary Heater)		+			

VITO/VIANO (639)

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	CDI 3 (Common Rail Diesel Injection)	+	+			
	ETC	+	+			
	ESM	+	+			
CHASSIS	ESP	+	+			
	ENR	+	+			
	TPC	+				
BODY	AB (SRS / Airbag)	+	+			
	OCP		+			
	UCP	+	+			
	SAM	+	+			
	EIS		+			
	SDE-H		+			
	AAG		+			

INFO. and COMMUNICATION	ICM (Instrument Cluster)		+		Service Reset / Oil Quality	
	PTS	+	+			
	APS		+			
SEATS AND DOORS	DCM FL	+	+			
	DCM FR	+	+			
	ESA – Driver	+	+			
	ESA – Passenger		+			
	ESD-L (Left Electric Sliding Door)		+			
	ESD-R (Right Electric Sliding Door)		+			
	AIR CONDITION	TAC / TAU (Tempmatic Air conditioning)	+	+		
	REAR-AC		+			
	PTC (Electric Heater Booster)	+	+			
	STH (Stationary Heater)	+	+			

VARIO

SYSTEM		DATA STREAM	READ / CLEAR CODES	ACTIVATION	ADAPTATION	INITIAL CODING
DRIVE	ME 2.0 / 2.1	+	+	+	+	+
	CDI 1 (Common Rail Diesel Injection)	+	+			
	CDI 2 (Common Rail Diesel Injection)	+	+	+		
	IFI	+	+			
CHASSIS	ABS	+	+			
BODY	AB (SRS / Airbag)	+	+			