



CHRYSLER 1995-2007

August 2011

For CAN-PROTOCOL, 2004-2007

POWER TRAIN SYSTEM

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
PCM (Power-train Control Module)	+	+	+	Exhaust Throttle Plate Adaptive Learn Position
TCM (Transmission Control Module)	+	+	+	Reset Learned Adaptives
ESM (Electronic Shifter Module)	+	+	+	

CHASSIS SYSTEM

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
ABS (Anti Lock Brakes)	+	+	+	Initialize Steering Angle Sensor Program Tire Size
ACC (Adaptive Cruise Control)	+	+		
ASBS (Automatic Sway Bar System)	+	+		
AWD (All Wheel Drive)	+	+	+	
TM (Trailer Tow Module)	+	+	+	
PTCM (Power Top Control Module)	+	+		

BODY SYSTEM

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
AHBM (Automatic High Beam Module)	+	+		
DDM (Drivers Door Module)	+	+	+	

EOM (Electronic Overhead Module)	+	+	+	
FCM (Front Control Module)	+	+	+	Program Tire Size
FDCM (Final Drive Control Module)	+	+	+	
HIDT (High Intensity Discharge Translator)	+	+	+	
HSM (Heated Seat Module)	+	+	+	
ITM (Intrusion Module)	+	+	+	
LRSM (Light Rain Sensor Module)	+	+		
MSMD (Memory Seat Module)	+	+	+	
OCM (Occupant Classification Module)	+	+		OCS Verification
ORC (Occupant Restraint Controller)	+	+	+	
PLGM (Power Lift Grate Module)	+	+	+	
PDM (Passengers Door Module)	+	+	+	
PTS (Parktronics)	+	+	+	
SCM (Steering Column Module)	+	+	+	
SUNR (Sunroof Module)	+	+	+	
PTIM (Police/Taxi Interface Module)	+	+	+	
SAS (Steering Angle Sensor)	+	+		
DMFL (Door Module Front Left)	+	+	+	
DMFR (Door Module Front Right)	+	+	+	

INFORMATION AND COMMUNICATION

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
AMP (Amplifier)	+	+		
CCN (Cabin Compartment Node)	+	+	+	Service Interval(GAS/DIESEL) Unlock Driver Door On 1st Press Auto Door Lock Auto Door Unlock Change Measurement Units Seatbelt Alert System Language Preference Turn By Turn Navigation
HFM (Hands Free Module)	+	+	+	
RADIO	+	+	+	
SDAR (Satellite Digital Radio)	+	+		

VES (Vehicle Entertainment System)	+	+		
VES3 (Second Row Monitor)	+	+	+	
WCM (Wireless Control Module)	+	+		Program Tire Sensor ID Program Ignition Keys Program Key FOBs Erase Ignition Key

AIR CONDITION

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
HVAC (Heat Ventilation and A/C)	+	+	+	

For OTHER PROTOCOL, 1995-2007

ENGINE

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
ENGINE	+	+	+	System Test A/C Data Set (KWP) Enable Cruise (KWP)

TRANSMISSION & T-CASE

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
TRANSMISSION MODULE(TCM)	+	+	+	Reset Learned Adaptives
TRANSFER CASE MODULE(TCASE)	+	+	+	
SHFT LEVER ASSEMBLY MODULE(SLA)		+	+	
FINAL DRIVE CONTROL MODULE(FDCM)	+	+		

ANTI-LOCK BRAKES

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
ANTI-LOCK BRAKES(ABS)	+	+	+	

PASSIVE RESTRAINTS

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
AIRBAG	+	+	+	
RIGHT SIDE AIRBAG(RSA)	+			

LEFT SIDE AIRBAG(LSA)	+			
AIRBAG ON/OFF SWITCH SYSTEM(SRM)	+		+	
OCCUPANT CLASSIFICATION SYSTEM(OCM)	+		+	OCS Verification

BODY INTERIOR

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
BODY COMPUTER	+	+	+	Program Tire Size
ELECTRO/MECH CLUSTER(MIC)	+	+	+	

INFO, COMM & ENTERTAINMENT

OVERHEAD CONSOLE(OHC, CMTC, EVIC)	+	+		Program Tire Sensor ID
AUDIO	+	+	+	
DIGITAL AUDIO AMPLIFIER(DAA, AMP)	+	+		
SATELLITE AUDIO RECEIVER(SAR)	+		+	
NAVIGATION SYSTEM(NAV)	+			
HANDS FREE MODULE(HFM)	+	+	+	

DOORS, GATE & COMFORT

DRIVER DOOR(DDM)	+	+	+	
PASSENGER DOOR(PDM)	+	+	+	
RIGHT SLIDING DOOR(RSD)	+	+	+	
LEFT SLIDING DOOR(LSD)	+	+	+	
POWER LIFT MODULE(PLGM)	+	+	+	
MEMORY SEAT MODULE(& APM)(MSM)	+	+	+	
ADJUSTABLE PEDAL MODULE(APM)	+	+	+	

HEATING & A-C

HVAC	+	+	+	
AUTOMATIC TEMP CONTROL(ATC)	+	+	+	
CABIN HEATER MODULE(CHM)	+	+	+	
FCM/IPM(A48)	+	+	+	
SERIAL BUS TRAVELER(SBT)	+	+	+	

CHASSIS & BODY EXTERIOR

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
---------------	---------------------------	--------------------	-------------------	-------------------

PARK ASSIST MODULE(PAM)	+	+		
RAIN SENSOR MODULE(RSM)	+			
TIRE PRESSURE MONITOR(TPM)	+	+		Program Module Program Pressure Sensor
SPEED PRO STEERING(SPS)	+	+		

THEFT ALARM

SYSTEM	READ / CLEAR FAULT	DATA STREAM	ACTIVATION	ADAPTATION
VTSS	+	+	+	
SKIM-SKREEM-TPM, IMMOBILIZER	+	+	+	Program Ignition Keys Add Individual Keys Program Key FOBs